



KMS-30
02/2025



FR

Cet appareil, ses
cordons, ses accessoires
et ses batteries sont
recyclables

**À DÉPOSER
EN MAGASIN**



ou

**À DÉPOSER
EN DÉCHÈTERIE**




Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
2. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
3. Warning: This product has a built-in lithium polymer battery.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Do not expose to heat, water, moisture, direct sunlight!

Parts Description



1. Power button:

2. "+" key

3. "-" key

4. Reverb key

5. Indicator light

6. Speaker

7. USB-C

8. AUX

1. Power button:

-Long press to turn on the machine, long press to turn off the machine.

-Short press to turn off the microphone, then short press to turn on the microphone .

2. "+" key:

-Short press volume up.

-Long press the next song.

-Double-click the microphone volume up.

3. "-" key:

-Short press volume down.

-Long press the previous song.

-Double-click microphone volume down .

4. Reverb key:

-Short press to turn on/off the reverb tone.

-Long press to switch the "magic sound"(Continuous long press to toggle through five sound effects).

"magic sound":Transforms sounds into different sound effects

-Double-click to cancel the music soundtrack.

5.Indicator light

- Blue light blinks after powering on.
- Blue light is always on after connecting Bluetooth successfully.

6.Speaker

5W RMS

7.USB-C charging port

- Plug the included USB-C cable (small end) into the USB-C port of the karaoke
- Plug the USB-A end (large end) into standard USB power adapter outlet.
- When charging , the red indicator light is always on.
- When fully charged , the indicator light off.

8.AUX

AUX input for playing music

Basic operation instructions

1. Long press the power button to turn on the machine, the blue working indicator light flashes in the boot state, open the device to search for bluetooth ‘KMS-30’ , the indicator light will be long lit after successful connection.
2. Enter the song list to play music, short press "+" key for volume up, short press "-" key for volume down. Long press "+" key to select the next song, long press "-" key to select the previous song.
3. When the microphone is on, short press the reverb key to turn on/off the reverb tone. Long press reverb key to switch magic sound.

Features

5W RMS output

Bluetooth 5.0

AUX input

Operating range up to 10 meters

Built-in battery with 5-6 hours playtime (1200mAh)

Input: 5V-1A

Power consumption:1.2W


Standby consumption:0.08W

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type KMS-30 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number:KMS-30 Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range:2402-2480MHz

Max Output Power:1.2W

DENVER A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, nº 23 - nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal:
Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Monday - Thursday 09:00 - 16:30
Friday 09:00 - 14:00

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**
E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 - 18 (poniedziałek - piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu



Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

