



Please read carefully.




**GAS-500**

[denver-electronics.com](http://denver-electronics.com)

April 2021

Plug in both USB plug and 3.5mm minijack plug into a PC. The USB gives power to the amplifier and the light, and the minijack is for the audio itself. Then adjust the volume to the level you require.

1. Volume control box
2. Volume adjuster
3. Audio input Jack
4. USB Power supply
5. Left Speaker
6. Right Speaker



Note: The appearance of the speaker is for reference only, please refer to the actual product.

## Essential parameters

Input power: USB power supply(5V, 0.5-1A)

Speaker specifications: 2 inch \*2

SNR:  $\geq 85\text{dB}$

Speaker unit:  $4\Omega$

Charging voltage: USB-- 5V

Distortion:  $\leq 0.5\%$

Speaker material: High gloss plastic

Amplifier output power: RMS  $3\text{W} \times 2$  (THD=10%)

Input interface: 3.5mm stereo input.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER ELECTRONICS  
A/S

  
www.denver-electronics.com



Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

DENVER ELECTRONICS A/S  
Omega 5A, Soeften  
DK-8382 Hinnerup  
[www.facebook.com/denverelectronics](https://www.facebook.com/denverelectronics)

We suggest that you contact us on e-mail: (Please write in English or Danish) as it is much easier for us to provide you with the support you require this way.

## Remember to include:

Accurate description of the error. With pictures if possible. Model number  
If there is an issue with the app , then please send the brand and model number of your phone along with your Email address and phone number so that we can contact you.

For technical questions, please send to:

[support@denver-electronics.com](mailto:support@denver-electronics.com)

For all other questions, please write to:

[intersales@intersales.eu](mailto:intersales@intersales.eu)

It is also possible to give us a call (in English or Danish), but we suggest you use email.

Phone no. : +45 86 22 61 00 - Please push 2 for "support" at welcome menu.  
(mo-th 8.00-16.00 + fr 8.00-14.30)

Fax no. : +45 86 22 81 00

## Denver Electronics A/S

Omega 5A, Soeften

DK-8382 Hinnerup

[denver-electronics.com](http://denver-electronics.com)

Made in China