PQC-10008

denver.eu

July/2025

FR
Cet appareil est recyclable
À DÉPOSER EN MAGASIN
OU
À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Important safety information

WARNING: Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Please keep the product away from pets.
3. Warning this power bank is with lithium polymer battery inside
4. Do not try to open the powerbank.
5. Do not expose to heat, water, moisture, direct sunlight!
6. Do not attempt to replace the battery yourself- you may damage the battery, which could cause overheating and injury. Repairs or service should only be performed by qualified personnel.
7. battery must be recycled or disposed of separately from household waste. Do not incinerate the battery.
8. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
9. Please remove the the charging cable when the power bank is fully charged.
10. Product operating and storage temperature is from 5 degree Celsius to 35 degree Celsius. Under and over this temperature might affect the function.
11. Do not drop or expose to impact shock in any way.

Power bank ports

1.Power button

2.Battery indicator

3.USB-A 2 Output

4.USB-A 1 Output

5.Micro USB Input

6.USB-C Input/output



Specifications

Battery capacity: 10000mAh

Fast charge: 22,5W

With LED battery indicator light

USB-A 1 Output: 5V/2A 9V/2A 10V/2,25A

USB-A 2 Output: 5V/2A 9V/2A 10V/2,25A

Micro Input: 5V/2A 9V/2A 12V/1,5A

Type-C Input: 5V/2A 9V/2A 12V/1,5A

Type-C Output: 5V/2A 9V/2A 12V/1,67A

Charging the power bank

Connect the USB-A to your adapter/charger and connect the USB-C to the power bank. The battery LED indicator will light up and start blinking according to the level of power in the power bank: There are 4 LEDS displaying battery capacity:

1. LED light: 0%-25%
2. LED lights: 25%-50%
3. LED lights: 50%-75%
4. LED lights: 75%-100%

Charging your device using the power bank

Plug the cable into the USB port on the power bank, the other end goes into your device. Battery LED indicator will light up, and your device is now charging. Click ON/OFF button to turn on the indicator, it will shut off automatically.

If there are only one or two LEDS, the power bank needs to be charged. After you have charged your device, recharge the power bank before using it again.

Maintenance of power bank

If the power bank is not used for a long time, it is best to store it with half power, fully charged storage will reduce the service life, empty power storage may cause over-discharge, of which both are bad to the power bank.
To clean the product surface, use only a dry, soft cloth, do not use chemicals, soap or detergents.

Warning!

Lithium battery inside!
Do not try to open the product!
Do not expose to heat, water, moisture or direct sunlight!
Only charge with the original charger supplied with this product!

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S

denver.eu

Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

DENVER A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, n° 23 – nave 16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal:
Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Monday - Thursday 09:00 - 16:30
Friday 09:00 - 14:00

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**
E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
contact.hq@denver.eu

Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

22
PAP