



# Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference

- 1. This product is not a toy. Keep it out of reach of children.
- 2. Warning: This product includes lithium polymer batteries.
- 3. Keep product out of the reach of children and pets to avoid chewing and swallowing
- Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
- 5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel. 6. Do not expose to heat, water, moisture, direct sunlight!
- 7. Please remove the earphones in case of any leakage or excessive heat from the product to avoid burns or rash.
- 8. Please protect your ears against loud volume. Loud volume can damage your ears.
- 9. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment
- 10. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
- 11. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit. stop use immediately



Delivery Content 1. Two earbuds (L USB charging cable 3. Charging case 4. Instruction manual

# Usage Instructions

## 1. Pairing the earbuds with your smartphone



Step 1. The earbuds would turn on once the cover of charging case is opened (no need to take the earbuds out of it first), or long press the touch panels of both earbuds to turn on the earbuds, with voice prompt of 'Power on'.

Step 2. RED and WHITE LED would start blinking on both the earbuds. Both of the earbuds would automatically pair with each other within 5 secs.

Once they are paired with each other, one of the earbuds would show a RED and WHITE LED blinking alternatively, which means they are ready to pair. with your smartphone.

Step 3. Now switch on Bluetooth in your smartphone to search for nearby devices and pair with the name 'Denver TWE-49' with voice prompt 'Connected' after the pairing succeed. Enter '0000' if prompted for password.

The earbuds would re-connect with smartphone automatically after pairing.

## Notes

The L or R earbud can be used alone to pair with your smartphone, and thus only mono sound is available.

## 2 During Music Playback

2.1 Touch the L or R panel ONCE to Play / Pause the track 2.2 Touch the L or R panel TWICE to skip to Next track 2.3 Touch the L or R panel THREE TIMES to skip to Prev. track 2.4 Long touch the L or R panel for 3 seconds to trigger the Siri or Google Assistant

## 3. During Calls

3.1 Touch the L or R panel ONCE to attend the incoming call / end the call. 3.2 Touch the L or R panel for 2 seconds to reject the incoming call. With total 4 mics for perfect calls (ENC): The earbuds will reduce the wind and noise interference, so your words always come through loud and clear.

## 4. Charge the Earbuds & Charging Case

4.1 Put the earbuds back into the charging case and close the cover of it. All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites the earbuds power off and start charging automatically. or be collected from the households. Additional information is available at the technical depart 4.2 When the Case is charging, the case indicator blinks, and indicator glows ment of your city. when the case is fully charged. Hereby, Denver A/S declares that the radio equipment type DENVER TWE-49ENC is in compli-

## 5 Product Parameters

Model name: TWE-49ENC Bluetooth version: 5.3 Bluetooth name: Denver TWE-49 (L / R / Both Earbuds) Standby time: Approx. 20 hours Music time: 6.5 hours Earbuds battery capacity: 3.7V 40 mAh x L / R Charging case battery capacity: 3.7V 230 mAh

Please notice - All products are subject to change without any notice We take reservations for errors and omissions in the manual.

# EN

## ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S

# **denver**

Electric and electronic equipment and included batteries contains materials, components and substances that can be bazardous to your health and the environment if the waste materials (discarded electric and electronic equipment and batteries) are not handled correctly.

Electric and electronic equipment and batteries are marked with the crossed out trash can symbol, as below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately

As the end user it is important that you submit your used batteries to the appropriate and desigpated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment

ance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: Please enter: denver.eu and then click the search ICON on topline of website Write model number: TWE-49ENC. Now enter product page and red directive is found under downloads/other downloads Operating Frequency Range: 2402 MHz - 2480 MHz Max Output Power: 4 dbm

DENVER A/S Omega 5A. Soeften DK-8382 Hinnerun Denmark www.facebook.com/denver.eu

Warning: Lithium battery inside 

## Denver A/S reserve the rights for print errors

Denver A/S cannot be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice. If you detect any inaccuracies or omissions, please inform us at the address on the back cover.

## Contact

EN

## Nordice

Headquarter Denver A/S Omena 54 Soefter DK-8382 Hinnerup Denmark

Phone: +45 86 22 61 00 (Push "1" for support)

E-Mail For technical questions, please write to support.hg@denver.eu

For all other questions please write to: contact.ho@denver.eu

### Benelux

DENVED BENELLIX B V Barwoutswaarder 13C+D 3449 HE Woerden The Netherlands

Phone: 0900-3437623

E-Mail-support.nl@denver.eu

### Spain/Portugal

#### DENVED SDAIN S A Ronda Augustes y Louis Lumiere, nº 23 - nave 16 Parque Tecnológico 46980 PATERNA Valencia (Spain)

Spain Phone: +34 960 046 883 Mail-support es@denver.eu

Portugal Dhone: +35 1255 260 296 F-Mail-denver service@satfiel.com



DENVED A/S Omena 54 Soeften DK-8382 Hinnerup Denmark

denver ou facebook.com/denver.e

## Germany

Denver Germany GmbH Service Max-Emanuel-Str. 4 94036 Passau

Phone: +49 851 379 369 40

E-Mail support de@denver.eu

Fairfixx GmbH Repair and service Rudolf-Diesel-Str. 3 TOR 2 53859 Niederkassel

(for TV. E-Mobility/Hoverboards/Balanceboards. Smartphones & Tablets)

Tel.: +49 851 379 369 69 E-Mail: denver@fairfixx.de

### Austria

Lurf Premium Service GmbH Deutschetrasse 1 1230 Wien

Phone: +431 904 3085 E-Mail denver@lurfservice at

If your country is not listed above nlease write an email to support@denver.eu

