



**GMP-295**

**denver.eu**

4/2024



**FR**  
Cet appareil est recyclable

À DÉPOSER EN MAGASIN

À DÉPOSER EN DÉCHÈTERIE

OU




Points de collecte sur [www.quefairedemesdechets.fr](http://www.quefairedemesdechets.fr)  
Privilégiez la réparation ou le don de votre appareil !

# Safety information page

1. Keep product out of the reach of children 0-3 years and pets to avoid chewing and swallowing.
2. Never use old and new batteries or different types of batteries together. Remove the batteries when you are not using the system for a longer period of time. Check the polarity (+/-) of the batteries when inserting them in the product. Wrong positioning can cause an explosion.  
Batteries are not included.
3. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
4. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.

5. Do not expose to heat, water, moisture, direct sunlight!
6. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
7. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.

## Product description



# Function of buttons

**On/Off:** Use the On/Off button to turn the unit on or off.

**Reset:** Press the reset button to return to the game in the game list.

**Volume:** Press the Volume button to adjust the volume.

**Select:** Press to enter, pause or restart the game.

**Start/Pause:** Press to enter, pause or restart the game.

**Directional buttons:** Allows you to select games, set a direction or control the game.

**Function keys (A/B/X/Y)/C/Z):** Can only be used after entering the game.

# **Battery compartment**

Unscrew the battery cover before insert-ing the batteries. Insert the batteries with the positive (+) and negative (-) terminals as indicated in the battery compartment. The replace the battery cover and screw into place. This product used 3x AAA batteries (not included).

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED,  
COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

**DENVER A/S**

**Omega 5A, Soefte**

**DK-8382 Hinnerup**

**Denmark**

**[www.facebook.com/denver.eu](http://www.facebook.com/denver.eu)**

# Contact

## Nordics

Headquarter

Denver A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

Phone: +45 86 22 61 00

(Push "1" for support)

E-Mail

For technical questions, please write to:

[support.hq@denver.eu](mailto:support.hq@denver.eu)

For all other questions please write to:

[contact.hq@denver.eu](mailto:contact.hq@denver.eu)



# **Germany**

**Denver Germany GmbH Service**

**Max-Emanuel-Str. 4**

**94036 Passau**

**Phone: +49 851 379 369 40**

**E-Mail**

**support.de@denver.eu**

**Fairfixx GmbH**

**Repair and service**

**Rudolf-Diesel-Str. 3 TOR 2**

**53859 Niederkassel**

**(for TV, E-Mobility/Hoverboards/  
Balanceboards, Smartphones & Tablets)**

**Tel.: +49 851 379 369 69**

**E-Mail: denver@fairfixx.de**

# **Spain/Portugal**

**DENVER SPAIN S.A**

**Ronda Augustes y**

**Louis Lumiere, nº 23 - nave 16**

**Parque Tecnológico**

**46980 PATERNA**

**Valencia (Spain)**

**Spain**

**Phone: +34 960 046 883**

**E-Mail: [support.es@denver.eu](mailto:support.es@denver.eu)**

**Portugal:**

**Phone: +35 1255 240 294**

**E-Mail: [denver.service@satfiel.com](mailto:denver.service@satfiel.com)**

# **Benelux**

**DENVER BENELUX B.V.**

**Barwoutswaarder 13C+D**

**3449 HE Woerden**

**The Netherlands**

**Phone: 0900-3437623**

**E-Mail: [support.nl@denver.eu](mailto:support.nl@denver.eu)**

# **Austria**

**Lurf Premium Service GmbH**

**Deutschstrasse 1**

**1230 Wien**

**Phone: +43 1 904 3085**

**E-Mail: [denver@lurfservice.at](mailto:denver@lurfservice.at)**

---

**If your country is not listed above,  
please write an email to  
[support@denver.eu](mailto:support@denver.eu)**



DENVER A/S  
Omega 5A, Soefte  
DK-8382 Hinnerup  
Denmark

[denver.eu](http://denver.eu)  
[facebook.com/denver.eu](https://facebook.com/denver.eu)

