

GB

INSTRUCTION MANUAL TC-26

LOCATION OF CONTROL

1. ANTENNA
2. CD DOOR
3. TUNNING CONTROL
4. DIAL POINTER
5. OPEN / CLOSE
6. LED DISPLAY
7. REPEAT
8. FUNCTION SELECTOR
9. RANDOM
10. VOLUME +
11. PROGRAM
12. VOLUME –
13. SKIP –
14. STOP
15. PLAY / PAUSE
16. SKIP +
17. STANDBY

CD OPERATION

PROGRAM

Up to 20 tracks can be programmed for disc play in any order.

Be sure to press the “STOP” button before use.

1. Press the “PROGRAM” button, the display will show “01” and _ash.
2. Select desired track by using the “SKIP +” or “SKIP -” button.
3. Press the “PROGRAM” button again to confirm desired track into the program memory.
4. Repeat step 2 and 3 to enter additional tracks into the program memory.
5. When all the desired tracks have been programmed. Press the “PLAY/PAUSE” button to play the disc in the order you have programmed.
6. Press the “STOP” button twice to terminate programmed play and the program indicator will turn off.

REPEAT

Press the “REPEAT” button before or during playing CD, a single track or all the tracks can be repeated.

Each press switches the repeat mode as follows:

1 – REPEAT 1 (The repeat indicator is flashing)

2 – REPEAT ALL (The repeat indicator is steadily on)

3 – NORMAL PLAYBACK

Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Imported by:

DENVER ELECTRONICS A/S

Omega 5A

Soeften

8382 Hinnerup

Denmark

www.facebook.com/denverelectronics