


# Sound Bar User Manual

## Operating Introduction

a. Place the Soundbar on a flat and solid surface. Alternatively, you can wall mount the Soundbar with the screws provided. You can hear audio through the Soundbar using ONE of the following connections.

1. Connect to your television using one of the connectors.
  - HDMI-ARC connector on the TV (using an HDMI cable)
  - Optical output connector on the TV (using an optical cable)
  - Headphone jack (using the supplied audio cable with 3.5mm plug)
2. Connect to a Bluetooth enabled device.
3. Connect to a USB drive (stick) loaded with music files

b. Illustration of the Soundbar connectors for different connections



EN	EN
OPTICAL IN	OPTICAL IN
LINE IN	LINE IN
DC 19V IN	DC 19V IN

**Note: To hear TV audio through the Soundbar via Optical or HDMI-ARC connection, make sure that the LINE IN jack on the Soundbar is not plugged in.**

c. The control panel on the Soundbar



Press the /MODE button to switch the Soundbar on or to standby.

When the LINE IN jack is plugged in, press and hold the /MODE button to toggle the sources: **Line In -> Bluetooth -> USB Drive.**

When the LINE IN jack is not plugged in, press and hold the /MODE button to toggle the sources: **Bluetooth -> USB Drive -> HDMI-ARC -> Optical In.**

Press the / MUTE button to start or pause play.

Press and hold the / MUTE button to mute or restore volume.

Press the VOL+/ button to increase volume.




Press and hold the VOL+/ button to skip to next audio file during USB play.

Press the VOL-/ button to decrease volume.

Press and hold the VOL-/ button to skip to previous audio file during USB play.

d. Source selection shown on the LED display


	Line In source
	Bluetooth source











	USB source when connecting to a USB drive. USB source cannot be selected if no USB drive is connected.
	HDMI-ARC source
	Optical In source

**Notes:**

- “bt” (Bluetooth) flashes if the Soundbar is not paired or connected to a Bluetooth device.
- “bt (Bluetooth) lights up if the Soundbar is paired or connected to a Bluetooth device.
- When the Soundbar is switched to standby, the red light is turned on.

e. Remote control buttons



	Switch the product on or to standby
	Mute or restore volume
	Increase volume
	Decrease volume
	Skip to previous audio file during USB play
	Skip to next audio file during USB play
	Start or pause play during USB play
	Repeat audio play during USB play
	Select different preset sound settings
	Select an audio source

Press the EQ button to toggle different preset sound settings shown below.

Display	EQ mode
Eq0	Normal
Eq1	Rock
Eq2	Pop
Eq3	Classic
Eq4	Jazz
Eq5	Country

### **Technical Specifications**

Power/Amps::	Input: AC110~240V, 50/60Hz; Output: DC19V, 1.5A
Power consumption:	36W/Hour
Operating frequency range:	40hz-16Khz
Max output power:	40W (RED Standard)
Soundbar measurement:	80 x 6 x 6cm
Bluetooth name:	DSB-4010

### **Packing List**

- Soundbar
- User manual
- Audio cable (3.5 to 3.5mm)
- Screws x 2
- Remote control with batteries
- Power adapter

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER ELECTRONICS A/S

# DENVER®

www.denver-electronics.com



Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly.

Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the radio equipment type DSB-4010 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [www.denver-electronics.com](http://www.denver-electronics.com) and then click the search ICON on topline of website. Write [modelnumber: DSB-4010](#). Now enter product page, and red directive is found under downloads/other downloads

Operating Frequency Range: 40hz-16Khz  
Max Output Power: 40W

DENVER ELECTRONICS A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

[www.facebook.com/denverelectronics](http://www.facebook.com/denverelectronics)