BTL-324




LED BLUETOOTH SPEAKER

Package Includes:

- 1. Speaker
- 2. User manual
- 3. Micro USB charging cable
- 4. 3.5mm Aux-in Cable

Layout



- 1. Open on/off button: long press "1" for power on /power off.
- / Il Microphone/play/pause button: short press"2" for play /pause/pick up /hang off a call.
- Mode switch button: short press "3" to switch to Bluetooth/TF/USB/Aux mode.

- 5. Fig. 1 /+: volume up/next button: short press "5" for forward to next song; long press for volume up.
- 6. -/I : volume down/ previous button: short press "6"for previous to last song: long press for volume down.
- RESET
- 8. 3.5mm Aux-in port
- 9. Micro SD port
- 10. Micro USB(DC 5V for charging)
- 11. USB interface
- 12. LED indicator

Charging

Attention! Make sure that the built-in battery is fully charged before initial use.

Charge your speaker:

Insert one end of the micro USB or USB cable(included) to the speaker's micro USB or USB port and the other end to PC or USB charger. Voice prompts when battery is low. The red light on when charging, light off when full charge.

The battery is an integral part of the device, so please do not try to

extract or replace it, which can result in the warranty cancellation or the device damage.

Bluetooth Pairing

Turn on the speaker, search pairing name: BTL-324 from mobile phone Bluetooth or other device to pair. "BTL-324" on screen and a short beep from your speaker indicates successful pairing.

Hands-free function

When you receive a call, short press the button number "2" once to answer. The same operation is applied to hang up. Long press the button "2" to reject calls. Press the button "2" twice to recall the last number.

MP3 player

Attention! The file system of a micro SD or USB flash carrier is FAT32.

Maximum volume is 32 GB.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED. COPYRIGHT DENVER ELECTRONICS A/S



www.denver-electronics.com



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that

electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the radio equipment type BTL-324 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.denver-electronics.com and then click the search ICON on topline of website. Write model number: BTL-324. Now enter product page, and red directive is found under downloads/other downloads.

Operating Frequency Range: 130Hz~20KHz 2402MHz~2480MHz

Max Output Power:5W x 2

DENVER ELECTRONICS A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

www.facebook.com/denverelectronics