


## **Safety information**

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.


1. This product is not a toy. Keep it out of reach of children.
2. Keep product out of the reach of children and pets to avoid chewing and swallowing.
3. Product operating and storage temperature is from 0 degree Celsius to 40 degrees Celsius. Under and over this temperature might affect the function.
4. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
5. Do not expose to heat, water, moisture, direct sunlight!
6. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
7. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
8. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
9. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
10. Only charge with supplied Adaptor. The direct plug-in adaptor is used as disconnect device, the disconnect device shall remain readily operable. So, make sure there is space around the power outlet for easy access.
11. Do not use non original accessories together with the product as this can make the product functionality abnormal.

## What's in the Box?



### Connecting Your Sound Bar to Your TV or other sources:

Illustration of the Soundbar connectors for different connections:



### Turn on your sound bar:

1. Connect the Power Supplies to Sound Bar then power Insert Power Supplies to an AC outlet.
2. Placing the Soundbar on a flat and solid surface. Hold the Power button /MODE at the right side of the sound bar or Press RED key on the remote control to turn it on. When the Soundbar is switched to standby, the red dot is turned on.

**NOTE\*:** **AUTO OFF Function of LINE IN:** If the connected device plays for 60 minutes, the soundbar automatically turns to Standby to save power.

Hold down /Mute to disable or enable AUTO OFF function of LINE IN.

### Importance Notice for soundbar mounting on the wall:


- 1) Wall-mounted installation must be carried out by qualified personnel only. Incorrect assembly can result in severe personal injury and property damage! (If you intend to install this product yourself, you must check for installations such as electrical wiring and plumbing, which may be hidden inside or behind the wall.)
- 2) It is the installer's responsibility to verify and confirm that the wall will safely support the total load of the unit and wall brackets.
- 3) Additional tools (not included) are required for the installation.
- 4) Do not overtighten screws.
- 5) Use an electronic stud finder to check the wall type before drilling and mounting
- 6) The proposed height on the wall is 1.0~1.5meters

### The control panel on the Soundbar:



Symbol	Operation	
	Hold	Press
/MODE	Power On/ Standby	Toggle the Mode change: LINE IN → Bluetooth → USB Drive
/MUTE	disable or enable <b>AUTO OFF *</b>	Pause/Play (USB/Bluetooth Mode) Mute / No Mute
VOL+ /	Volume up	Next USB Drive/Bluetooth Song
VOL- /	Volume down	Next USB Drive/Bluetooth Song.

### Remote control buttons



	Switch the product on or to standby
	Mute or restore volume
<b>EQ</b>	Equalizer: <b>Eq0</b> : Normal, <b>Eq1</b> : Rock, <b>Eq2</b> : Pop, <b>Eq3</b> : Classic, <b>Eq4</b> : Jazz, <b>Eq5</b> : Country
	Decrease volume
	Increase volume
	Skip to previous audio file during USB/BT play
	Pause or play USB/BT audio file
	Skip to next audio file during USB/BT play
	Repeat audio during USB play
<b>MODE</b>	Select an audio source *

\*MODE (source) selection shown on the LED display.

	Line In source
	Bluetooth source <ul style="list-style-type: none"> <li>● Flashes if the Soundbar is not paired or connected to a bluetooth device.</li> <li>● Lights up if the Soundbar is paired.</li> </ul>
	USB source when connecting to a USB drive

### Technical Specifications

Power consumption:	20 W
Max output power:	28 W
Bluetooth version:	5.0
Operating frequency range:	2402-2480Mhz
Soundbar measurement:	60cm x 6 cm x 6 cm
Bluetooth name:	DSB-2010MK2

### Power Supplies Information:

Manufacturer:	SHENZHEN FIT-POWER TECHNOLOGY CO., LTD.
Commercial registration number:	91440300577672653M
Address:	201, NO.7 RIFU ROAD, EAST DISTRICT, BAISHIXIA COMMUNITY, FUYONG, BAOAN SHENZHEN
Trade mark	FIT-POWER
Model:	TP04-120200E
Input voltage:	100-240V~
Input AC frequency:	50/60Hz
Output voltage:	DC12V
Output current:	2.0A
Output power	24W
Max output power:	36W
Average active efficiency:	87%
Efficiency at low load (10%):	82%
No-load power consumption:	0.1W or less

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S declares that the radio equipment type DSB-2010MK2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [www.denver-electronics.com](http://www.denver-electronics.com) and then click the search ICON on topline of website. Write model number: DSB-2010MK2. Now enter product page, and red directive is found under downloads/other downloads.

Operating Frequency Range: 2402-2480Mhz

Max Output Power: 20 W

DENVER ELECTRONICS A/S

Omega 5A, Soeften

DK-8382 Hinnerup

Denmark

[www.facebook.com/denverelectronics](http://www.facebook.com/denverelectronics)

## Soundbar Brugervejledning